

DATA SHEET

DEVECO 232-EA

Deveco 232-EA is a non-etching aluminum cleaner which provides excellent cleaning ability without excessive foaming. The head of foam will seldom exceed 1/2 inch in height in the reservoir tank, even when high pressures are used. Deveco 232-EA is a high detergency, liquid product that can also be used to clean copper, brass and steel.

Deveco 232-EA has the following characteristics:

- Liquid formulation permits easy additions and is suitable for automatic pump applications.
- Effective in all equipment: Pressure spray, cylindrical screw conveyor, agitated basket-type.
- Prevents scale build-up on tank walls, pipes, nozzles and steam coils.
- Has long life and is economical to use.

MAKE UP:

Concentration	5 - 10%
Temperature	140 – 200 °F.

Do not operate the cleaner below 140 °F or foaming may become excessive.

Read Material Safety Data Sheet before using this product.

DISCLAIMER:

The information presented herein, while not guaranteed, is to the best of our knowledge true and accurate. No warranty or guarantee expressed or implied is made regarding the performance of any products, since the manner of use is beyond our control. No suggestion for product use or anything contained herein, shall be construed as a recommendation for its use in infringement of any existing patent and we assume no responsibility or liability for operations which do infringe any such patents. The above includes confidential and proprietary information of Deveco Corporation and is furnished to you for your use solely on products or processes supplied by us to you.

Dev-Kleen 232-EA Alkaline Soak Cleaner

ANALYSIS:

TITRATION KIT PROCEDURE:

- ★ Use the syringe to transfer 2 ml. of the sample to a clear glass bottle.

- ★ Add 2 or 3 drops of methyl orange indicator to the sample.

- ★ While “swirling” the solution, add 1.0N hydrochloric acid (HCl) dropwise until the solution changes from yellow to pink/orange . Make note of the number of drops used.

Drops. 1.0 N HCl

Dev-Kleen 232-EA Concentration

- 2	3%
- 3	5%
- 5	10
- 7	15
- 9	20

LABORATORY TITRATION PROCEDURE:

- ★ Take a 50 ml sample of the solution.
- ★ Add 3 or 4 drops of Methyl Orange indicator .
- ★ Titrate with 1.0N hydrochloric acid (HCl); End point: Yellow → Pink/Orange.

Calculation: % Dev-Kleen 232-EA = (2.5) X (mls 1.0N HCl)